

Silver Econo Roll



Econo Travel Bag
(26" x 4" x 4" / 35.5" x 4" x 4" / 37.5" 4" x 4")

*



Silver (24" & 33.5" & 36")

Product Features

The Econo Roll delivers a professional looking display at an economical price. Set up and break down of the display takes seconds and conveniently stores in its included padded travel bag. banner attached to the bottom of stand by double-sided tape and to the top by clamp bar

| | |
|-------------------|-------------|
| Display Dimension | 24"W x 80"H |
|-------------------|-------------|

| | |
|--------------|-------------|
| Graphic Size | 24"W x 80"H |
|--------------|-------------|

Graphic Material

Super Flat Vinyl

Graphic Finishing

5" bleed at the bottom

Construction

Sturdy aluminum construction

Weights - Dimensions

| | |
|-----------------|-------|
| Shipping Weight | 9 lbs |
|-----------------|-------|

| | |
|---------------------|---------------|
| Shipping Dimensions | 4"x 4"x 26.5" |
|---------------------|---------------|

Package Includes

Aluminum Pole

Telescopic Pole (Not Adjustable)

Econo Travel Bag

Warranty

1 Year on Stand

1 Year on Graphic

Graphic Specification

24"W x 80"H

Graphic Turnaround Time is 2 business days for up to 2 sets

Clamp Light

110V




PARTS LIST



(qty 1) Econoroll Retractable Stand



(qty 1) Clamp Bar



(qty 1) Support Pole



(qty 1) Econo Travel Bag

SET UP INSTRUCTIONS


Step 1

Twist the feet.




Step 2

Assemble telescopic pole.



Step 3

Insert telescopic pole into hole.




Step 4

Pull banner out of the base.



Step 5

Attach telescopic pole to the clamp bar.



Step 6

Complete stand.

