

ECONO ROLL 36"



Econo Travel Bag
(26" x 4" x 4" / 35.5" x 4" x 4" / 37.5" 4" x 4")



Silver (24" & 33.5" & 36")

Product Features

The Econo Roll delivers a professional looking display at an economical price. Set up and break down of the display takes seconds and conveniently stores in its included padded travel bag. banner attached to the bottom of stand by double-sided tape and to the top by clamp bar

Display Dimension	36"W x 80"H
-------------------	-------------

Graphic Size	36"W x 80"H
--------------	-------------

Graphic Material

Super Flat Vinyl

Graphic Finishing

5" bleed at the bottom

Construction

Sturdy aluminum construction

Weights - Dimensions

Shipping Weight	9 lbs
-----------------	-------

Shipping Dimensions	4"x 4"x 36"
---------------------	-------------

Package Includes

Aluminum Pole

Telescopic Pole (Not Adjustable)

Econo Travel Bag

Warranty

1 Year on Stand

1 Year on Graphic

Graphic Specification

36"W x 80"H

Graphic Turnaround Time is 2 business days for up to 2 sets

*



Clamp Light
110V


PARTS LIST



(qty 1) Econoroll Retractable Stand



(qty 1) Clamp Bar



(qty 1) Support Pole



(qty 1) Econo Travel Bag

SET UP INSTRUCTIONS


Step 1

Twist the feet.




Step 2

Assemble telescopic pole.



Step 3

Insert telescopic pole into hole.




Step 4

Pull banner out of the base.



Step 5

Attach telescopic pole to the clamp bar.



Step 6

Complete stand.

